

Corner Rounder Installation Instructions

Installation:

Hang Corner Rounder before you hang connecting shelves.
Takes up 19" of wall space on each wall.

1. Back Clip location

- Determine height of shelf.
- Make two level marks at 4" and 17" from corner on each wall. These marks must be level with marks for connecting shelves. The first mark for the connecting shelves will be 21" from corner of wall (figure 1).

2. Attaching Corner Rounder Shelf:

- Drill 1/4" holes at marks, insert Versa-Clips® and tighten (see instructions for Versa-Clip®).
- Snap Corner Rounder into Clips (figure 2).

3. Attaching to Connecting Shelves

- Snap connecting shelves into Versa-Clips® according to instructions, but do not attach Support Braces.
- Slide waste saver joiners over end rods connecting Corner Rounder to connecting shelves.
(2 small waste saver joiners for the middle rod, 2 large connectors for the top front rod).
- Secure bottom front rod with the Joiner Clip using nuts and bolts (figure 3).
- For 16" deep shelving, clips add 1 small waste saver joiner for front rod.

4. Insert Hold Down Clips:

- Use inverted Versa-Clips® above connecting shelves near waste saver joiners (see instructions for Versa-Clips®).

5. Attaching Support Braces:

- Hold connecting shelves level and attach 12" Support Braces within 2 inches from end of shelf.
- Attach Support Brace to top front rod and swing back to wall, mark and drill holes according to Support Brace instructions. Bring Support Brace back to wall, insert Tri-Loc® II Anchor and tighten (figure 4).

